

Processing instructions

The PVA–release film is a film forming release lacquer, which is dissolved in a mixture of alcohol and water. The film, which develops after the evaporation of the solvent mixture, is smooth and high gloss, non – toxic and furthermore insoluble in nearly all organic solvents. Therefore the release lacquer acts like a barrier against aggressive chemicals, so that the moulds are protected. The PVA–release film is applied with a soft brush, cloth or sponge and is dry after approx. 15-30 minutes.

After the demoulding process the release film can be peeled off like a foil. Possibly remaining residues can easily be removed with water.

In General

Sales units / packages: 1 l / 5 l

Storing

Keep away from sources of ignition

Do not store outdoors.

In case of extreme cold do stabilize to 15° C.

Shelf life is indicated on the labels

Safety measure

Please follow the precaution instructions of the Government Safety Organisation of the chemical industry when working with this material. Please follow safety advices !

Waste Disposal

According to arrangement with local authorities cured material can be disposed as domestic or commercial waste.

Non-cured products are waste which is subject to inspection and has to be disposed accordingly.

In case of further questions please do not hesitate to contact our Department for Product Safety.

The instructions and recommendations are given in good faith and are based on long experience and careful tests. Since the conditions of use are beyond our control, and due to versatility of applications and working methods, we can't give any guarantee. All information are non-binding and are no guarantee for special characteristics or properties of the product. Despite information given from **ebalta** the customer has to make his own tests regarding applications and processing. If any special warranty is requested, written agreement on this subject is essential.

ebalta Kunststoff GmbH . Erlbacher Straße 100 . 91541 Rothenburg ob der Tauber / Germany
Tel.: +49 9861 7007-0 . Fax: +49 9861 7007-77 . info@ebalta.de . www.ebalta.de